







Montageanleitung / Mounting instruction EM ready2apply 4W SM



Dimensions in mm



220-240 V
50/60 Hz

L
N
E
DA
DA

EM R2A PRO SM

220-240 V
50/60 Hz

L
N
E

EM R2A ST SM

220-240 V
50/60 Hz

L
N
E

EM R2A BASIC SM


Earth terminal (E)

The earth terminal is a loose connection without function. Use it to connect the earth wire to prevent it being loose in the luminaire. There is no earth connection required for the functionality of the EM ready2apply.




Installation must be performed by a qualified person.

Take care when drilling to prevent damage to internal components.






Klemmenbeschreibung / Terminal description



Akkuanschluss / Battery connection



Akkutausch / Battery exchange



! Do not damage battery and other components during battery replacement. / Beim Akkutausch Akku und sonstige Komponenten nicht beschädigen.

For re-connection of EM R2A start in reverse order. / Für Wiederanschluss des EM R2A in umgekehrter Reihenfolge starten.

For further product information refer to product datasheet at www.tridonic.com.
Für weitere Produktinformation siehe Produktdatenblatt auf www.tridonic.com.